



**Swissdigital Design backpack with massage function.**

**USER'S MANUAL**

Dear customer,

Thank you for choosing one of our products with the latest technology. Like our Swiss forebears, we blend precision with craftsmanship. Swissdigital Design stands for high-quality precision gear which are thoroughly tested.


Swissdigital Design has been the world's first company developing a USB charging system for backpacks. By using this system you can charge your phone hand-free, notebook or any other device, by using an additional power bank. This means that while you travel you will never run out of power!

Swissdigital Design also developed and patented a massage function for backpacks. By using this massage function from the backpack you will enjoy and feel relaxed and feel great during traveling!

Your Swissdigital Design team.

-1-

**USER'S MANUAL:**




Depending on the selected backpack, your bag comes with- or without a battery pack. In the latter case you should supply your own rechargeable battery pack. We recommend a minimum of 5000 mAh with at least two USB ports. For charging as well as massaging simultaneously we recommend a battery with 10,000 mAh.

**Power Consumption:**

The massage function consumes approximately 600 mAh for each hour. A 5000 mAh will provide you massaging for around 7 hours and a 10.000 mAh will supply approximately 14 hours of massaging.

-2-




The white cable is for your massage function

The black cable is for powering your devices.

**Step 1:**

- Open the bag for power bank inside the main body of the backpack.
- Connect the USB cable (white cable) to the external battery pack and turn on the power of the battery pack.


-3-



**Step 2:**

- Pass the webbing on both sides of the shoulder strap through the elastic bands on both sides and adjust the angle.
- The closer you fit the body, the more comfortable the massage will be. Also the sound will reduce.

-4-



The waist webbing can be adjusted. Please adjust it to a position that makes you feel comfortable and close to your body. The closer you are to your body, the lower the sound.

**Step 3:**


- Fasten the waist webbing buckle and adjust the angle of the waist webbing.
- The closer you are to the body, the more comfortable the massage will be, and at the same time, the sound will reduce.

-5-

**Step 5:**

- To turn the massage function ON by pressing the button on your right hand side on the control panel for 3-5 seconds.

- If you are unable to detect any massage motion please check if the power of your battery pack is ON.




Button

Shoulder straps massager

Lower back massager

-7-



- 1) The shoulder straps will vibrate once you turn it ON.
- 2) Press once and lower back massage will start vibrating.
- 3) Press twice and the shoulder as well as the lower back massage will vibrate.
- 4) Press and hold the button for 3-5 seconds and the vibration will shut off.

-8-

Depending on the selected backpack your bag comes with- or without a battery pack. In the latter case you should supply your own rechargeable battery pack. We recommend a minimum of 5000 mAh with at least two USB ports. For charging as well as massaging simultaneously we recommend a battery with 10,000 mAh.

Power consumption: The massage function consumes approximately 600 mAh for each hour. A 5000 mAh will provide you massaging for around 7 hours and a 10.000 mA will supply approximately 14 hours of massaging.

**FEATURES:**

**Sleeping mode:**

The massaging system will automatically shut off after 15 minutes of running. Please take a rest for 2 minutes before powering the device again. This might extend the life time of your battery and massaging system, also better for relaxing your body.

**Special remarks and advice:**

This product is only intended for the purpose described in these instructions for use. The manufacturer is not liable for damage resulting from improper or careless use. The device is intended to massage individual parts of the human body. Do not use the device on animals, injuries (e.g. burns, open wounds), pregnant women, after an operation or on sensitive parts of the body (e.g. head, joints). If you have a pacemaker or an implant or if you are not sure that the device is suitable for you, consult your doctor prior to use. For children's safety monitor their weight. It is recommended by doctors and therapists that children carry 10% max of their body weight in their bags. Do not submerge the product fully into water or washing machine or dishwasher as it will damage the electronics. It is possible to clean the bag with damp cloth and then dry with dry cloth of hang dry. Under no circumstances should you open or repair the device yourself, as faultless functionality can no longer be guaranteed thereafter. Failure to adhere to this instruction will void the warranty.

**Specifications:**


- Single group rated current: ≤200mA
- Double group rated current: ≤350mA
- Power supply interface: USB 2.0
- Voltage / Current: DCSV / 500mA
- Operating temperature: - 10°C ~ 50°C



-9-

**Special remarks:**

The positions A, B, and C shown in red are dedicated zippers for our after-sales service. Please do not use them unless there is a malfunction.




**Tips:**

Some powerbanks may enter hibernation mode if they remain inactive for an extended period, leading to an inability to power up our products. If you discover that your device won't turn on, please disconnect the powerbank once more.



-10-

This optional chest strap is available in our online web store for users who want to maximize their backpack adjustments.



Technology authorized by Swissdigital wearable AG  
For more information please visit our website www.swissdigital.eu  
Version 24-08-2021 V2.11. Errors and omissions accepted.

-11-



The shoulder strap is adjustable, please adjust it to a position that makes you feel comfortable and close to your body. The closer you are to your body, the lower the sound.

**Step 4:**

- Adjust the tightness of the shoulder strap, please adjust it to the angle that makes you feel comfortable and close to your body.
- The closer you are to the body, the more comfortable the massage will bring. The closer the bag is to your body, the lower the sound.

-6-